





▶ **TERMINAL TYPE**


TC018-N11AXX □ □ □ □




TC018-N11BXX □ □ □ □



TC018-N11A1XX □ □ □ □




TC018-N11B1XX □ □ □ □




▶ **CAP TYPE**


R TYPE




R1 TYPE




R1A TYPE




S TYPE




S1 TYPE



R2 TYPE




R3 TYPE




▶ **CIRCUIT**

SINGLE COLOR



TWO COLOR



TACT SWITCH

PUSH BUTTON SWITCH

LED TOUCH SENSOR SWITCH

5 DIRECTION NAVIGATION SWITCH WITH LED

MEMBRANE SWITCH

LED LIGHT BAR

SLIDE SWITCH

ROTARY SWITCH

ROCKER SWITCH

DETECT SWITCH

ENCODER

INTERRUPTER

MINIATURE MICRO SWITCH

TELEPHONE HOOK SWITCH

DOOR SWITCH

MINI SIZE SOCKET

KNOB

CAP SYMBOL